

# CANON

Model	Vignetting	Digital Adapter			Adapter Ring Size	Recommended Eyepiece	Additional Adapters
		DA1	VA1	DA4			
PowerShot Pro 90 IS	×	-	●	-	58mm	V	
PowerShot S2 IS	▲	-	●	-	58mm	V	Lens Adapter LAH-DC20
PowerShot S1 IS	▲	-	●	-	52mm	V	Lens Adapter LA-DCS52E
PowerShot Pro1	×	-	●	-	58mm	V	Lens Adapter LA-DCS58C
PowerShot S70	●	-	-	●	-	W	
PowerShot S60	●	-	-	●	-	W	
PowerShot S50	●	-	-	●	-	W	
PowerShot G1	▲	●	-	-	58mm	L	Lens Adapter LA-DC58
PowerShot G2	▲	●	-	-	58mm	L	Lens Adapter LA-DC58
PowerShot G3	▲	●	-	-	58mm	L	Lens Adapter LA-DC58B
PowerShot G5	▲	●	-	-	58mm	L	Lens Adapter LA-DC58B
PowerShot G6	▲	●	-	-	58mm	L	Lens Adapter LA-DC58D
PowerShot A95	●	●	-	●	52mm	W	Lens Adapter LA-DC52D
PowerShot A80	●	●	-	●	52mm	W	Lens Adapter LA-DC52D
PowerShot A70	●	●	-	●	52mm	W	Lens Adapter LA-DC52C
PowerShot A60	●	●	-	●	52mm	W	Lens Adapter LA-DC52C
PowerShot A50	●	●	-	●	52mm	W	Lens Adapter LA-DC52C
PowerShot A45	●	●	-	●	52mm	W	Lens Adapter LA-DC52B
PowerShot A40	●	●	-	●	52mm	W	Lens Adapter LA-DC52B
PowerShot A30	●	●	-	●	52mm	W	Lens Adapter LA-DC52B
PowerShot A20	●	●	-	●	52mm	W	Lens Adapter LA-DC52
PowerShot A10	●	●	-	●	52mm	W	Lens Adapter LA-DC52
PowerShot A400	●	-	-	●	-	W	
PowerShot A310	●	-	-	●	-	W	
PowerShot A300	●	-	-	●	-	W	

PowerShot A200	●	-	-	●	-	W
PowerShot A100	●	-	-	●	-	W
IXY Digital 600	●	-	-	●	-	W
IXY Digital 500	●	-	-	●	-	W
IXY Digital 450	●	-	-	●	-	W
IXY Digital 400	●	-	-	●	-	W
IXY Digital 320	●	-	-	●	-	W
IXY Digital 55	●	-	-	●	-	W
IXY Digital 50	●	-	-	●	-	W
IXY Digital 40	●	-	-	●	-	W
IXY Digital 30a	●	-	-	●	-	W
IXY Digital 30	●	-	-	●	-	W
IXY Digital L	●	-	-	●	-	W

#### Sheet Key

Vignetting	Amount of vignetting is broken down into three ratings ranging from best to worst [●], [▲], [✕] <b>[ CAUTION ]</b> Even with a rating of [●], vignetting may occur at some point in the camera's zoom range.
Digital Adapter	[●] : Camera can be used with adapter. [▲] : Camera can be used with adapter but TSN-VA1 is recommended. [-] : Camera can not be used with adapter.
Recommended Eyepiece	Use of this eyepiece will result in the least amount of vignetting. W : Wide Angle Eyepiece (TSE-14WE/WD, TSE-21WE/WD) L : Long Eye Relief Eyepiece (TSE-17HE/17HD) V : Photo and Video Adapter (TSN-VA1)

# CASIO

Model	Vignetting	Digital Adapter			Adapter Ring Size	Recommended Eyepiece	Additional Adapters
		DA1	VA1	DA4			
QV-R61	●	-	-	●	-	W	
QV-R51	●	-	-	●	-	W	
QV-R40	●	-	-	●	-	W	
QV-R4	●	-	-	●	-	W	
EX-S 100	●	-	-	●	-	W	
EX-Z750	●	-	-	●	-	W	
EX-Z57	●	-	-	●	-	W	
EX-Z55	●	-	-	●	-	W	
EX-Z50	●	-	-	●	-	W	
EX-Z40	●	-	-	●	-	W	
EX-Z30	●	-	-	●	-	W	
EX-P700	●	●	-	●	58mm	L	Adapter Set LU-60A
EX-P600	●	●	-	●	58mm	L	Adapter Set LU-60A
EX-P505	●	●	●	-	43mm	V/L	
QV-5700							
QV-4000	●	●	-	●	58mm	L	Lens Adapter LU-35A
QV-3500EX	●	●	-	●	58mm	L	Lens Adapter LU-35A
QV-2900UX	●	▲	●	-	43mm	V	
QV-2800UX	●	▲	●	-	43mm	V	

QV-2400UX	●	●	-	43mm	W	Lens Adapter LU-8A
QV-2300UX	●	●	-	43mm	W	Lens Adapter LU-8A

### Sheet Key

Vignetting Amount of vignetting is broken down into three ratings ranging from best to worst [●], [▲], [✕]  
**[ CAUTION ]**  
 Even with a rating of [●], vignetting may occur at some point in the camera's zoom range.

Digital Adapter [●] : Camera can be used with adapter.  
 [▲] : Camera can be used with adapter but TSN-VA1 is recommended.  
 [-] : Camera can not be used with adapter.

Recommended Eyepiece Use of this eyepiece will result in the least amount of vignetting.  
 W : Wide Angle Eyepiece (TSE-14WE/WD, TSE-21WE/WD)  
 L : Long Eye Relief Eyepiece (TSE-17HE/17HD)  
 V : Photo and Video Adapter (TSN-VA1)

# FUJI FILM

Model	Vignetting	Digital Adapter			Adapter Ring Size	Recommended Eyepiece	Additional Adapters
		DA1	VA1	DA4			
HD-1	×	-	●	-		W	
Finepix S7000	▲	▲	●	-	55mm	V	Adapter AR-FX9
Finepix S5000	▲	▲	●	-	55mm	V	Adapter AR-FX5
Finepix S304	▲	▲	●	-	55mm	V	Adapter AR-FX9
Finepix F810	●	-	-	●	-	W	
Finepix F710	●	-	-	●	-	W	
Finepix F700	●	-	-	●	-	W	
Finepix F550	●	-	-	●	-	W	
Finepix F450	●	-	-	●	-	W	
Finepix F440	●	-	-	●	-	W	
Finepix F420	●	-	-	●	-	W	
Finepix F410	●	-	-	●	-	W	
Finepix E550	●	●	-	●	43mm	W	Adapter Ring AR-FXE02
Finepix E510	●	●	-	●	43mm	W	Adapter Ring AR-FXE01
Finepix A430	●	-	-	●	-	W	
Finepix A330	●	-	-	●	-	W	
Finepix A310	●	-	-	●	-	W	

Finepix 6900z	▲	-	●	-	55mm	V	Adapter Ring AR-FX9
Finepix 4900z	▲	-	●	-	55mm	V	Adapter Ring AR-FX9

### Sheet Key

Vignetting Amount of vignetting is broken down into three ratings ranging from best to worst [●], [▲], [×]  
**[ CAUTION ]**  
 Even with a rating of [●], vignetting may occur at some point in the camera's zoom range.

Digital Adapter [●] : Camera can be used with adapter.  
 [▲] : Camera can be used with adapter but TSN-VA1 is recommended.  
 [-] : Camera can not be used with adapter.

Recommended Eyepiece Use of this eyepiece will result in the least amount of vignetting.  
 W : Wide Angle Eyepiece (TSE-14WE/WD, TSE-21WE/WD)  
 L : Long Eye Relief Eyepiece (TSE-17HE/17HD)  
 V : Photo and Video Adapter (TSN-VA1)

# KODAK

Model	Vignetting	Digital Adapter			Adapter Ring Size	Recommended Eyepiece	Additional Adapters
		DA1	VA1	DA4			
DC4800	●	●	-	-	43mm	W	Lens Adapter FA-4800
DX7630	●	●	-	-	37mm	W	DX7630 Lens Adapter
DX7590	●	▲	●	-	55mm	V	DX7590 Lens Adapter
DX7440	●	●	-	-	37mm	W	DX7440 Lens Adapter
DX6490	●	▲	●	-	55mm	V	DX6490 Lens Adapter
DX6440	●	●	-	-	37mm	W	DX6440 Lens Adapter
DX6340	●	●	-	-	37mm	W	DX6340 Lens Adapter
DX4900	●	●	-	-	37mm	W	DX4900 Lens Adapter
DX4530	●	●	-	-	37mm	W	DX4530 Lens Adapter
DX4330	●	●	-	-	37mm	W	DX4330 Lens Adapter
DX3900	●	●	-	-	37mm	W	DX3900 Lens Adapter

Sheet Key	
Vignetting	Amount of vignetting is broken down into three ratings ranging from best to worst [●], [▲], [✕] <b>[ CAUTION ]</b> Even with a rating of [●], vignetting may occur at some point in the camera's zoom range.
Digital Adapter	[●] : Camera can be used with adapter. [▲] : Camera can be used with adapter but TSN-VA1 is recommended. [-] : Camera can not be used with adapter.
Recommended Eyepiece	Use of this eyepiece will result in the least amount of vignetting. W : Wide Angle Eyepiece (TSE-14WE/WD, TSE-21WE/WD) L : Long Eye Relief Eyepiece (TSE-17HE/17HD) V : Photo and Video Adapter (TSN-VA1)

# KONICA/MINOLTA

Model	Vignetting	Digital Adapter			Adapter Ring Size	Recommended Eyepiece	Additional Adapters
		DA1	VA1	DA4			
DiMAGE G600	●	-	-	●	-	W	
DiMAGE G530	●	-	-	●	-	W	
DiMAGE G400	●	-	-	●	-	W	
DiMAGE Z3	▲	▲	●	-		V	
DiMAGE Z2	▲	▲	●	-	52mm	V	Adapter ZCA-100
DiMAGE Z1	▲	▲	●	-	52mm	V	Adapter ZCA-100
DiMAGE 7Hi	×	▲	●	-	52mm	V	Step-Up Ring 49-52mm
DiMAGE 7i	×	▲	●	-	52mm	V	Step-Up Ring 49-52mm
DiMAGE 7	×	▲	●	-	52mm	V	Step-Up Ring 49-52mm
DiMAGE F300	●	-	-	●	-	W	
DiMAGE F200	●	-	-	●	-	W	
DiMAGE F100	●	-	-	●	-	W	
DiMAGE A2	×	▲	●	-	52mm	V	Step-Up Ring 49-52mm
DiMAGE A1	×	▲	●	-	52mm	V	Step-Up Ring 49-52mm
DG-4W	▲	●	-	-	37mm		

## Sheet Key

Vignetting	Amount of vignetting is broken down into three ratings ranging from best to worst [●], [▲], [×] [ CAUTION ] Even with a rating of [●], vignetting may occur at some point in the camera's zoom range.
Digital Adapter	[●] : Camera can be used with adapter. [▲] : Camera can be used with adapter but TSN-VA1 is recommended. [-] : Camera can not be used with adapter.
Recommended Eyepiece	Use of this eyepiece will result in the least amount of vignetting. W : Wide Angle Eyepiece (TSE-14WE/WD, TSE-21WE/WD) L : Long Eye Relief Eyepiece (TSE-17HE/17HD) V : Photo and Video Adapter (TSN-VA1)



# KYOCERA

Model	Vignetting	Digital Adapter			Adapter Ring Size	Recommended Eyepiece	Additional Adapters
		DA1	VA1	DA4			
Finecam S3R	●	-	-	●	-	W	
Finecam S5R	●	-	-	●	-	W	
Finecam M410R	●	▲	●	-	52mm	V	Adapter ring 49/52m
Finecam L30	●	-	-	●	-	W	
Finecam L4	●	-	-	●	-	W	
Finecam L3	●	-	-	●	-	W	

Sheet Key	
Vignetting	Amount of vignetting is broken down into three ratings ranging from best to worst [●], [▲], [×] <b>[ CAUTION ]</b> Even with a rating of [●], vignetting may occur at some point in the camera's zoom range.
Digital Adapter	[●] : Camera can be used with adapter. [▲] : Camera can be used with adapter but TSN-VA1 is recommended. [-] : Camera can not be used with adapter.
Recommended Eyepiece	Use of this eyepiece will result in the least amount of vignetting. W : Wide Angle Eyepiece (TSE-14WE/WD, TSE-21WE/WD) L : Long Eye Relief Eyepiece (TSE-17HE/17HD) V : Photo and Video Adapter (TSN-VA1)

# NIKON

Model	Vignetting	Digital Adapter			Adapter Ring Size	Recommended Eyepiece	Additional Adapters
		DA1	VA1	DA4			
COOLPIX 4800	▲	-	-	●	-	V	
COOLPIX 4100	●	-	-	●	-	W	
COOLPIX 4200	●	-	-	●	-	W	
COOLPIX 5200	●	-	-	●	-	W	
COOLPIX 2200	●	-	-	●	-	W	
COOLPIX 8800		-	-	-			
COOLPIX 8700	●	▲	●	-	52mm	V	Adapter Tube DC-B7
COOLPIX 7900	●	-	-	●	-	W	
COOLPIX 5900	●	-	-	●	-	W	
COOLPIX 3200	●	-	-	●	-	W	
COOLPIX 3700	●	-	-	●	-	W	
COOLPIX 5400	▲	●	-	-	28mm	L	Lens Adapter UR-E11
COOLPIX SQ	●	-	-	●	-	W	
COOLPIX 3100	●	-	-	●	-	W	
COOLPIX 2100	●	-	-	●	-	W	
COOLPIX 2000	●	-	-	●	-	W	
COOLPIX 5700	▲	-	●	-	52mm	V	Raynox RT5253NW, RT5253NT
COOLPIX 4500	●	●	-	-	28mm	W	
COOLPIX 5000	●	●	-	-	28mm	L	Lens Adapter UR-E6
COOLPIX 995	●	●	-	-	28mm	W	
COOLPIX 990	●	●	-	-	28mm	W	
COOLPIX 950	●	●	-	-	28mm	W	
COOLPIX 4300	●	●	-	●	28mm	W	Lens Adapter UR-E4

COOLPIX 885	●	●	-	●	28mm	W	Lens Adapter UR-E4
COOLPIX 880	●	●	-	●	28mm	W	Lens Adapter UR-E2
COOLPIX 800	●	●	-	●	28mm	W	
COOLPIX 775	●	●	-	●	28mm	W	Lens Adapter UR-E3

### Sheet Key

Vignetting	Amount of vignetting is broken down into three ratings ranging from best to worst [●], [▲], [✕] <b>[ CAUTION ]</b> Even with a rating of [●], vignetting may occur at some point in the camera's zoom range.
Digital Adapter	[●] : Camera can be used with adapter. [▲] : Camera can be used with adapter but TSN-VA1 is recommended. [-] : Camera can not be used with adapter.
Recommended Eyepiece	Use of this eyepiece will result in the least amount of vignetting. W : Wide Angle Eyepiece (TSE-14WE/WD, TSE-21WE/WD) L : Long Eye Relief Eyepiece (TSE-17HE/17HD) V : Photo and Video Adapter (TSN-VA1)

# OLYMPUS

Model	Vignetting	Digital Adapter			Adapter Ring Size	Recommended Eyepiece	Additional Adapters
		DA1	VA1	DA4			
CAMEDIA C-70		-	-	●	-	L	
CAMEDIA E-10	×	-	-	-	-		
CAMEDIA E-100RS	▲	-	●	-	52mm	V	Step-Up Ring 49-52mm
CAMEDIA C-8080	×	-	-	-	-		
CAMEDIA C-7070	●	●	-	-	52mm	W/L	Kenko C-7070 Conversion Lens Adapter
CAMEDIA C-5060	●	●	-	-	52mm	L	Reynox RT5248 or Kenko C-5060 CLA
CAMEDIA C-5050	●	●	-	-	43mm	L	Lens Adapter CLA-1
CAMEDIA C-4040	●	●	-	-	43mm	L	Lens Adapter CLA-1
CAMEDIA C-3040	●	●	-	-	43mm	L	Lens Adapter CLA-1
CAMEDIA C-3030	●	●	-	-	43mm	L	Lens Adapter CLA-1
CAMEDIA C-2040	●	●	-	-	43mm	L	Lens Adapter CLA-1
CAMEDIA C-2020	●	●	-	-	43mm	L	Lens Adapter CLA-1
CAMEDIA C-4100	●	●	-	-	43mm	L	Lens Adapter CLA-1
CAMEDIA C-3100	●	●	-	-	43mm	L	Lens Adapter CLA-1
CAMEDIA C-2100	▲	▲	●	-	52mm	L	Step-Up Ring 49-52mm
CAMEDIA C-770	▲	▲	●	-	55mm	V	Lens Adapter CLA-4
CAMEDIA C-760	▲	▲	●	-	55mm	V	Lens Adapter CLA-4
CAMEDIA C-755	▲	▲	●	-	55mm	V	Lens Adapter CLA-4
CAMEDIA C-750	▲	▲	●	-	55mm	V	Lens Adapter CLA-4
CAMEDIA C-745	▲	▲	●	-	55mm	V	Lens Adapter CLA-4
CAMEDIA C-730	▲	▲	●	-	55mm	V	Lens Adapter CLA-4
CAMEDIA C-720	▲	▲	●	-	55mm	V	Lens Adapter CLA-4
CAMEDIA C-700	●	▲	●	-	55mm	V	Lens Adapter CLA-4
u-40 DIGITAL	●	-	-	●	-	W	
u-30 DIGITAL	●	-	-	●	-	W	
u-25 DIGITAL	●	-	-	●	-	W	

u-15 DIGITAL	●	-	-	●	-	W
u-20 DIGITAL	●	-	-	●	-	W
u-10 DIGITAL	●	-	-	●	-	W
X-500	●	-	-	●	-	W
X-450	●	-	-	●	-	W
X-350	●	-	-	●	-	W
X-250	●	-	-	●	-	W
X-200	●	-	-	●	-	W
X-3	●	-	-	●	-	W
X-1	●	-	-	●	-	W
X-2	●	-	-	●	-	W
C-2	●	-	-	●	-	W
C-1	●	-	-	●	-	W

#### Sheet Key

Vignetting	Amount of vignetting is broken down into three ratings ranging from best to worst [ ● ], [ ▲ ], [ ✕ ] <b>[ CAUTION ]</b> Even with a rating of [ ● ], vignetting may occur at some point in the camera's zoom range.
Digital Adapter	[ ● ] : Camera can be used with adapter. [ ▲ ] : Camera can be used with adapter but TSN-VA1 is recommended. [ - ] : Camera can not be used with adapter.
Recommended Eyepiece	Use of this eyepiece will result in the least amount of vignetting. W : Wide Angle Eyepiece (TSE-14WE/WD, TSE-21WE/WD) L : Long Eye Relief Eyepiece (TSE-17HE/17HD) V : Photo and Video Adapter (TSN-VA1)

# PANASONIC

Model	Vignetting	Digital Adapter			Adapter Ring Size	Recommended Eyepiece	Additional Adapters
		DA1	VA1	DA4			
DMC-LC70	●	-	-	●	-	W	
DMC-LC43	●	-	-	●	-	W	
DMC-LC40	●	●	-	-	52mm	L	Lens Adapter DMW-LA1
DMC-LC33	●	-	-	●	-	W	
DMC-LC20	●	-	-	●	-	W	
DMC-LC5	●			-	52mm		Lens Adapter DMW-LA1
DMC-LC1					55mm		Step-Down Ring 82-55mm and DMW-LST69
DMC-FX8	●	-	-	●	-	W	
DMC-FX7	●	-	-	●	-	W	
DMC-FX5	●	-	-	●	-	W	
DMC-FX3	●	-	-	●	-	W	
DMC-FX2	●	-	-	●	-	W	
DMC-FX1	●	-	-	●	-	W	
DMC-FZ30	×	▲	●	-	72mm	V	
DMC-FZ20	×	▲	●	-	72mm	V	
DMC-FZ10	×	▲	●	-	72mm	V	
DMC-FZ5	▲	▲	●	-	55mm	V	
DMC-FZ3	×	▲	●	-	55mm	V	
DMC-FZ2	×	▲	●	-	55mm	V	

DMC-FZ1	×	▲	●	-	55mm	V
DMC-F1	●	-	-	●	-	W

### Sheet Key

Vignetting Amount of vignetting is broken down into three ratings ranging from best to worst [●], [▲], [×]  
**[ CAUTION ]**  
 Even with a rating of [●], vignetting may occur at some point in the camera's zoom range.

Digital Adapter [●] : Camera can be used with adapter.  
 [▲] : Camera can be used with adapter but TSN-VA1 is recommended.  
 [-] : Camera can not be used with adapter.

Recommended Eyepiece Use of this eyepiece will result in the least amount of vignetting.  
 W : Wide Angle Eyepiece (TSE-14WE/WD, TSE-21WE/WD)  
 L : Long Eye Relief Eyepiece (TSE-17HE/17HD)  
 V : Photo and Video Adapter (TSN-VA1)

# Pentax

Model	Vignetting	Digital Adapter			Adapter Ring Size	Recommended Eyepiece	Additional Adapters
		DA1	VA1	DA4			
Optio S50	●	-	-	●	-	W	
Optio S40	●	-	-	●	-	W	
Optio S30	●	-	-	●	-	W	
Optio SV		-	-	●	-	L	
Optio S	●	-	-	●	-	W	
Optio 33LF	●	-	-	●	-	W	
Optio 33L	●	-	-	●	-	W	
Optio 330GS	●	-	-	●	-	W	
Optio 430RS	●	-	-	●	-	W	
Optio 330 RS	●	-	-	●	-	W	
Optio 30	●	-	-	●	-	W	
Optio 230	●	-	-	●	-	W	

## Sheet Key

Vignetting Amount of vignetting is broken down into three ratings ranging from best to worst [●], [▲], [✕]  
**[ CAUTION ]**  
 Even with a rating of [●], vignetting may occur at some point in the camera's zoom range.

Digital Adapter [●] : Camera can be used with adapter.  
 [▲] : Camera can be used with adapter but TSN-VA1 is recommended.  
 [-] : Camera can not be used with adapter.

Recommended Eyepiece Use of this eyepiece will result in the least amount of vignetting.  
 W : Wide Angle Eyepiece (TSE-14WE/WD, TSE-21WE/WD)  
 L : Long Eye Relief Eyepiece (TSE-17HE/17HD)  
 V : Photo and Video Adapter (TSN-VA1)



# Sanyo

Model	Vignetting	Digital Adapter			Adapter Ring Size	Recommended Eyepiece	Additional Adapters
		DA1	VA1	DA4			
DSC-S5	●	-	-	●	-	W	
DSC-S4	●	-	-	●	-	W	
DSC-S3	●	-	-	●	-	W	
DSC-S1	●	-	-	●	-	W	
DSC-C1	●	-	-	●	-	W	
DSC-AZ1	●	-	-	●	-	W	
DSC-MZ3	●	-	-	●	-	W	
DSC-MZ2	●	-	-	●	-	W	

## Sheet Key

Vignetting Amount of vignetting is broken down into three ratings ranging from best to worst [●], [▲], [✕]  
**[ CAUTION ]**  
 Even with a rating of [●], vignetting may occur at some point in the camera's zoom range.

Digital Adapter [●] : Camera can be used with adapter.  
 [▲] : Camera can be used with adapter but TSN-VA1 is recommended.  
 [-] : Camera can not be used with adapter.

Recommended Eyepiece Use of this eyepiece will result in the least amount of vignetting.  
 W : Wide Angle Eyepiece (TSE-14WE/WD, TSE-21WE/WD)  
 L : Long Eye Relief Eyepiece (TSE-17HE/17HD)  
 V : Photo and Video Adapter (TSN-VA1)

# SONY

Model	Vignetting	Digital Adapter			Adapter Ring Size	Recommended Eyepiece	Additional Adapters
		DA1	VA1	DA4			
Cyber-shot DSC-P200	●	●	-	●	30mm	W	Lens Adapter VAD-PHC
Cyber-shot DSC-P150	●	●	-	●	30mm	W	Lens Adapter VAD-PHB
Cyber-shot DSC-P100	●	●	-	●	30mm	W	Lens Adapter VAD-PHB
Cyber-shot DSC-U40	●	-	-	●	-	W	
Cyber-shot DSC-U30	●	-	-	●	-	W	
Cyber-shot DSC-W1	●	●	-	●	30mm	W	Lens Adapter VAD-WA
Cyber-shot DSC-W5	●	●	-	●	30mm	W	Lens Adapter VAD-WA
Cyber-shot DSC-W7	●	●	-	●	30mm	W	Lens Adapter VAD-WA
Cyber-shot DSC-V3	×	●	-	-	58mm	L	Lens Adapter VAD-VHA
Cyber-shot DSC-V1	▲	●	-	-	52mm	L	Lens Adapter LA-DC
Cyber-shot DSC-F717	×	▲	●	-	58mm	V	
Cyber-shot DSC-F828	×	▲	●	-	58mm	V	
Cyber-shot DSC-F707	×	▲	●	-	58mm	V	
Cyber-shot DSC-F505V	▲	▲	●	-	52mm	V	
Cyber-shot DSC-F55DX	●	●	-		30mm	W	
Cyber-shot DSC-P73	●	●	-	●	30mm	W	Lens Adapter VAD-PHB
Cyber-shot DSC-P43	×	-	-	●	-	W	
Cyber-shot DSC-P8	●	●	-	●	30mm	W	Lens Adapter VAD-PHA
Cyber-shot DSC-P10	●	●	-	●	30mm	W	Lens Adapter VAD-PHA
Cyber-shot DSC-P92	●	●	-	●	30mm	W	Lens Adapter VAD-PEA
Cyber-shot DSC-P72	●	●	-	●	30mm	W	Lens Adapter VAD-PEA
Cyber-shot DSC-P50	●	●	-	●	37mm	W	

Cyber-shot DSC-P30	●	●	-	●	37mm	W	
Cyber-shot DSC-S85	●	●	-		52mm	L	Lens Adapter VAD-S70
Cyber-shot DSC-S75	●	●	-		52mm	L	Lens Adapter VAD-S70
Cyber-shot DSC-S70	●	●	-		52mm	L	Lens Adapter VAD-S70
Cyber-shot DSC-S50	●	●	-		37mm	W	
Cyber-shot DSC-S30	●	●	-		37mm	W	

<b>Sheet Key</b>	
Vignetting	Amount of vignetting is broken down into three ratings ranging from best to worst [●], [▲], [✕] <b>[ CAUTION ]</b> Even with a rating of [●], vignetting may occur at some point in the camera's zoom range.
Digital Adapter	[●] : Camera can be used with adapter. [▲] : Camera can be used with adapter but TSN-VA1 is recommended. [-] : Camera can not be used with adapter.
Recommended Eyepiece	Use of this eyepiece will result in the least amount of vignetting. W : Wide Angle Eyepiece (TSE-14WE/WD, TSE-21WE/WD) L : Long Eye Relief Eyepiece (TSE-17HE/17HD) V : Photo and Video Adapter (TSN-VA1)